















ELITE

SCHEMA DI MONTAGGIO/ *assembling scheme*ALLUNGO PER SCRIVANIE
extension for executive desks


LAS

CODICE
code 777 700 862DISEGNO
drawing SM 74002DATA
date 31-07-2019PAGINA
page 1/3INDICE DI REVISIONE N°
last revision no 5DATA REVISIONE
last date 19/04/2021SCHEMA DI MONTAGGIO
assembling schemeN.B. PER IL MONTAGGIO
SEGUIRE LE FASI NUMERATE
assemble following the numbered phases

CODE	COLOUR	CODE	Ø x L	CODE	Ø x L	COLOUR	CODE	Ø	COLOUR	CODE	COLOUR	CODE	Ø x L	COLOUR	CODE	COLOUR	CODE	Ø x L	CODE	Ø x L	COLOUR	CODE	COLOUR	CODE	Ø	COLOUR	CODE	Ø	COLOUR	
504407001	NERO black	505060902	8 x 30	505041903	7,5 x 36	ZINCATO	505030811	14	BRUNITA 9/16"	506072218	BRUNITA burnished	506942808	4,5 x 40	BRUNITA 3/16" x 1 9/16" - burnished	505030717	NERO black	505060901	10 x 30	505041902	10 x 36	ZINCATO 3/8" x 1 3/8" - zinc plated	505041936	ZINCATO zinc plated	505030812	16	BRUNITA 5/8"	506062108	BRUNITA burnished	505132353	NERO53 black 53
	P x 4		Q x 36		R x 30			S2 x 30			T x 30		U4 x 8			V x 4		B x 6		C x 4		G x 4		D x 12		E x 12		I x 12		


FASI / phases 1-2-3-4

POSIZIONARE UN CARTONE SUL PAVIMENTO E
ASSEMBLARE I COMPONENTI DELLO ZOCCOLO
put the cardboard on the floor and assemble
the components of the plinth



FASI / phases 5-6-7

FISSARE LO ZOCCOLO CON LA BASE ROVESCATA A TERRA
fix the plinth to the base overturned on the floor





SEGUE
assembling in the following page



FASI / phases -8-9-10-11

ESEMPIO DI MONTAGGIO ALLUNGO DX
example of assembling right extension

**FASI / phases 12-13-14-15****FASI / phases 16-17-18-19-20**

- 16** **AVVICINARE L'ANTA IN POSIZIONE APERTA**
bring the door closer to the open position
- 17** **INSERIRE LE CERNIERE A SCOMPARSA NEI FORI**
insert the concealed hinges into the holes
- 18** **SERRARE LE VITI PER ESPANDERE**
tighten the screws to expand
- 19** **INSERIRE PUSH**
insert the magnetic push
- 20** **INSERIRE IL RISCONTRO**
insert the metallic stud


CERNIERE A SCOMPARSA
concealed hinges

CODE	COLOUR
507078019	OTTONE
C2	<i>brass</i>



CODE	COLOUR
505051109	NERO <i>black</i>

CODE	COLOUR
505051130	ARGENTO
	<i>silver</i>




M

X

PUSH
MAGNETICO
magnetic push

**RISCONTRO
METALLICO**
metallic stud



8 **SERRARE LE VITI**
PER ESPANDERE
tighten the screws
to expand

FASI / phases 21-22-23

